GH-1322 LATHE

PARTS LIST



Table of Contents

Table of Contents 1

Bed Assembly 2-6

Headstock Assembly 7-12

Gear Box Assembly 13-18

Apron Assembly 19-23

Top Slide Toolpost Saddle and Cross Slide 24-27

Saddle and Cross Slide Assembly (Telescoping Lead Screw) 28-29

Tailstock Assembly 30-32

Follow Rest 33

Steady Rest 34-35

Quick Change Collet Assembly 36-37

Bed Assembly



Bed Assembly



Bed Assembly



Bed Assembly

Index No.	Part No.	Description	Size	Qty
1	01110	Motor Base		1
2	01106	Pulley		1
3	GHB1340A-01101	Bed		1
4	01102	Gap		1
5	01215	End Cover		1
6	01104	Bracket		1
7	01105	Bracket		1
9	01201	Collar		1
10	01202	Handle		1
11	01203	Rack		1
13	01204-2	Rack		1
16	01205-3	Lead Screw		1
19	01206-3	Feed Rod		1
22	01207-3	Shaft		1
23	01208	Collar		1
24	01209	Shaft		1
25	01210	Handle		1
26	01211	Brake Ring		1
27	01212	Collar		1
28	01213	Key		1
	01214-3	Oil Pan (not shown)		1
39	01501	Knob		1
40	01502	Plug		1
41	01503	Plug		1
42	01504	Plug		1
43	04244	Screw		2
44	04510	Cover		1
45	04247	Lock Nut		2
46	TS-1522021	Set Screw	M5X8	1
47A	TS-1523051	Set Screw	M6X16	1
49	TS-1505061	Hex Socket Cap Screw	M10X40	4
51	TS-1503051	Hex Socket Cap Screw	M6X20	3
52	TS-1540061	Hex Socket Cap Screw	M8X55	2
53	TS-1540061	Hex Nut	M8	4
54	GHB1340-54B	Screw	M8X28	2
54A	TS-1492061	Hex Cap Bolt	M12X60	6
58	GHB1340-58B	Pin	3X25	1
59	GHB1340-59B	Pin	8n6X25	1
61	GHB1340-61B	Pin	6X28	1
61A	GHB1340-61AB	Pin	6X55	1
67	GHB1340-67B	Spring	1 X 7.5 X 25	3

68	GHB1340-68B	Oil Ball	8	2
69	GHB1340-69B	Pin	8X60	2
70	GHB1340A-70B	Hex Cap Bolt	M10X35	3
71	GHB1340A-71B	Screw	M6X8	2
72	GHB1340A-72B	Screw	M5X6	4
73	18702	Cover		1
74	18701	Electrical Box		1
75	12701	Splash Guard		1
76	GHB1340A-76B	Screw	M6X10	4
77	GHB1340A-77B	Screw	M6X20	4
78	GHB1340A-78B	Nut	M6	4
79	CO632B-01703A	Oil Plate		1
79A	CO632B--01703	Oil Plate		1
80	GHB1340A-80B	Screw	M6X10	4
81	01720/11	Cover		1
82	CO632B--01701A	Left Bed Stand		1
82A	CO632B--01701	Right Bed Stand		1
83	CO632B-01702	Bed Stand		1
84	01708A	Cover		2
85	GHB1340A-85B	Screw	M6X10	2
86	GHB1340A-86B	Screw	M6X10	4
87	01720/9	Cover		1
88	GHB1340A-88B	Screw	M12X50	6
89	01722	Bracket		1
90	GHB1340A-90B	Screw	M6X10	6
91	01724	Plate		1
92	01723	Bracket		1
93	22709G	Break Shaft		1
94	GHB1340A-94B	Split Pin	2x12	1
95	22705	Brake Pull Rod		1
96	22713	Cap-Shape Screw		1
97	GHB1340A-97B	Nut	M6	1
98	GHB1340A-98B	Split Pin	2X12	1
99	22101G	Pedal Arm		1
100	22703	Connecting Shaft		1
101	22704	Draw Spring		1
102	22705G	Switch Block		1
103	GHB1340A-103B	Screw	M8X8	1
104	GHB1340A-104B	Pin	5X40	1
105	22704	Drving Shaft-Longer		1
106	GHB1340A-106B	Spring Pin	5X30	3
107	22707G	Drving Shaft		1
108	22712G	Pedal		1
109	GHB1340A-109B	Screw	M10X60	1
110	GHB1340A-110B	Nut	M10	1
111	22702	Butt Rod Support		1

Headstock Assembly



Headstock Assembly



Headstock Assembly



Headstock Assembly

Index No.	Part No.	Description	Size	Qty.
1	04101N	Collar		1
2	04102	Collar		2
3	04103N	Rear Cover		3
4	04104Z	Rear Cover		4
5	04105	Pulley		1
6	04106	Plug		1
7	04107Z	Main Casting		1
8	04108Z	Front Cover		1
9	04109	Shift Lever		1
10	04111	Shaft Housing		1
11	04112	Cover		1
12	04117	Handle Body		1
13	04121	Shaft Collar		1
14	04120	Handle Body		1
15	04119	Handle Block		1
16	04118	Hub		1
17	04201	Gear	37T	1
18	04202Z	Washer		2
19	04203Z	Washer		1
20	04204	Washer		1
21	04205	Gear	40T	1
22	04206	Washer		1
23	04207	Gear	37T	1
24	04208	Lock Nut		2
25	04209	Gear	43T	1
26	04210	Gear	51T	1
27	04211	Washer		1
28	04212	Gear Shaft	16T	1
29	04213	Cover		1
30	04214Z	Washer		1
31	04215	Shaft		1
32	04216	Washer		1
33	04217	Collar w/Gear	21T	1
34	04218	Gear	29T	1
35	04219	Gear	46T	1
36	04220	Gear	38T	1
37	04221	Collar		1
38	04222	Gear	26T	1
39	04223	Gear	34T	1
40	04224	Gear	53T	1
41	04225	Plug		1
42	04226	Gear	74T	1
43	04227	Gear	37T	1
44	04228Z	Spindle		1

45	04229	Spring		3
46	04230	Pin		3
47	04231	Cam		3
48	04232	Shaft		1
50	04234	Gear	51T	1
51	04235	Collar		1
52	04250	Shaft		1
53	04237	Gear	30T	1
54	04238	Shaft		1
55	04239N	Shaft		1
56	04240	Washer		1
57	04241	Gear Shaft	17T	1
59	04243 Z	Screw		2
64	04248	Handle		2
65	04248-1	Handle		1
66	04249	Handle		1
67	04401	Collar		2
68	04402	Shift Fork		1
69	04403	Shift Fork		1
73	04501	Gasket		1
74	04502	Gasket		1
75	04503N	Gasket		1
76	04504N	Gasket		1
77	04505	Gasket		1
78	04506	Gasket		1
79	GB13871	Oil Seal	B-22 X 35X7	1
80	04508	Oil Seal		1
	04511	Oil Sight Glass (not shown)		1
84	TS-1501041	Hex Socket Cap Screw	M4×12	3
85	TS-1502041	Hex Socket Cap Screw	M5×16	3
86	TS-1503031	Hex Socket Cap Screw	M6×16	3
87	TS-1504041	Hex Socket Cap Screw	M8×20	4
88	TS-1523051	Hex Socket Cap Screw	M6×20	4
89	TS-1523061	Hex Socket Cap Screw	M6×25	10
93	TS-1523041	Set Screw	M6×12	2
95	TS-1524011	Set Screw	M8×8	1
96	TS-1524021	Set Screw	M8×10	2
97	TS-1524031	Set Screw	M8×12	2
98	TS-1524041	Set Screw	M8×16	1
99	GHB1340-99	Screw	M8×40	2
100	GHB1340-100	Screw	M4×8	4
102	TS-1540081	Hex Nut	M12	1
103	GHB1340-103	Key	5×15	2
104	GHB1340-104	Key	5×18	1
105	GHB1340-105	Key	5×50	1
106	GHB1340-106	Key	6×40	1

107	GHB1340-107	Key	6×55	2
108	GHB1340-108	Key	6×120	1
109	GHB1340-109	Key	6×120	1
110	GHB1340-110	Key	8×18	1
111	GHB1340-111	Key	5×20	1
113	GHB1340-113	Pin	3×10	1
114	GHB1340-114	Pin	4×18	1
116	GHB1340-116	Pin	5×32	1
117	GHB1340- 117	C-Clip	20	3
119	GHB1340-119	C-Clip	35	1
120	GHB1340-120	C-Clip	50	2
121	GHB1340-121	C-Clip	72..	1
122	GHB1340-122	C-Clip	42	2
123	GHB1340-123	Bearing	700104E	2
124	GHB1340-124	Bearing	240E	1
125	GHB1340-125	Bearing	203	2
126	GHB1340-126	Bearing	204D	2
127	GHB1340-127	Bearing	7210E	1
128	GHB1340-128	Bearing	7212D	1
129	GHB1340-129	Steel Ball	5	1
130	GHB1340-130	Steel Ball	6	2
133	GHB1340-133	O-Ring	2.4×14	2
134	GHB1340-134	O-Ring	2.4×20	1
135	GHB1340-.135	O-Ring	2.4×25	1
136	GHB1340-.136	O-Ring	3.1×30	1
137	GHB1340-137	O-Ring	3.1×40	1
138	GHB1340-138	O-Ring	3.1×47	1
139	GHB1340-139	Spring	1×6×7	1
140	GHB1340-140	Spring	1×6×25	1
141	GHB1340-141	Spring	0.9×4.4×19	4
142	04235A	Shift Hub		2
	GHB1340-143	Brass Pipe(not shown)	8×1×30	2
147	GHB1340-147	Lever	Sleeve	3
	VB-A32	V-Belt (not shown)		2
148	04125	Frame		1
149	GHB1340-149	Pin	6×60	2
150	GHB1340-150	Screw	M6×50	4
151	GHB1340-151	Hex Socket Cap Screw	M10×35	2
152	22708G	Connecting Board		1
153	GHB1340A-153	Pin	5 X25	1
154	22709G	Shaft.		1
155	22701	Break Shaft		1
156	GHB1340A-156	Circlip	12	1
157	GHB1340A-157	Break Shoet		1
158	22701G	Positioning Axle		1
159	GHB1340A-159	Circlip	8	1

Gearbox Assembly



Gearbox Assembly



Gearbox Assembly



Gearbox Assembly

Index No.	Part No.	Description	Size	Qty
1	0511	Casting		1
2	0552	Right cover		1
3	0551	Left cover		1
4	0508	Slipper		3
5	0510	Lever		1
6	0509	Lever		1
7	0553	Slipper		1
8	0504	Shaft		1
9	0503	Handle base		1
10	0501	Lever & ball		2
11	0502	Handle base		1
13	05113	Cover		1
14	0507	Gasket		1
15	0530	Slipper		1
17	0531	Handle		1
18	0449	Plate		2
19	0532	Handle		1
21	0529	Cover		1
22	0525	Gasket		1
23	0539	Shaft		1
24	0538	Gear		1
25	0544	Washer		1
27	0550	Gear		1
28	0546	Nut		1
29	0547	Gasket		1
30	0548	Bush		1
31	0549	Washer		1
32	05271	Shaft		1
33	0528	End cover		1
34	0527	Gasket		1
35	0541	Shaft		1
36	0536	Gear		1
37	0537	Gear		1
38	0540	Gear		1
39	0542	Washer		1
40	0543	Washer		1
41	0544	Washer		2
42	0522	Gear		1
43	0521	Gear		1

44	0519	Gear		1
45	0518	Gear		1
46	0517	Gear		1
47	0516	Gasket		1
48	0514	Flange		1
49	05270	Shaft		1
50	0526	End Cover		1
52	0524	Gear		1
53	0520	Gear		1
54	0523	Key Shaft		1
56	0513	Cover		1
57	0511	Copper Sleeve		1
58	05269	Gear		1
59	05266	Collar		1
60	05268	Screw		1
61	05267	Washer		2
62	0533	Washer		2
63	05258	Gear		1
64	05112	Gear Frame		1
65	05249	Screw rod		1
66	0529	Cover		1
67	GHB1340A-G67	Screw	M4X8	8
68	GHB1340A -G68	Nut	ZG3/8"	2
69	GHB1340A -G69	Screw	M8x65	3
70	GHB1340A -G70	Screw	M6X20	7
71	GHB1340A -G71	Screw	M6X14	17
72	GHB1340A -G72	Pin	5x20	1
73	GHB1340A -G73	Pin	5x40	2
74	GHB1340A -G74	Pin	5x50	1
75	GHB1340A -G75	Cover	M10X50	2
76	GHB1340A -G76	Spring	0.8x5x15	2
77	GHB1340A -G77	Spring	0.8x5x25	2
78	GHB1340A -G78	Screw	M8x6	4
79	GHB1340A -G79	Ball Steel	Φ6.5	4
80	GHB1340A -G80	Circlip	40	2
81	GHB1340A -G81	Circlip	20	2
82	GHB1340A -G82	Circlip	22	2
83	GHB1340A -G83	O-Ring	34.5x2.6	1
84	GHB1340A -G84	O-Ring	25x2.6	1
85	GHB1340A -G85	Screw	M3x8	4
86	GHB1340A -G86	Key	5x8	1
87	GHB1340A -G87	Key	5x14	3
88	GHB1340A -G88	Key	5x50	3
89	GHB1340A -G89	Key	5x80	1

90	GHB1340A -G90	Thrust	202	6
91	GHB1340A -G91	Thrust	103	2
92	GHB1340A -G92	Thrust	104	2
93	GHB1340A -G93	Thrust	302	1
94	GHB1340A -G94	Thrust	8105	2
95	GHB1340A -G95	Circlip	35	2
96	GHB1340A -G96	Nut	M10	1
97	GHB1340A -G97	Nut	M10	3
98	GHB1340A -G98	Screw	M4x8	1

Apron Assembiy



Apron Assembiy



Apron Assembiy



Apron Assembly

Index No.	Part No.	Description	Size	Qty.
1	06101	Casting		1
2	06102	Handwheel		2
3	06103	Box		1
4	06104	Cover		1
5	06105	Threading Dial Body		1
5A	06105A	Hub		1
6	06206	Washer		1
7	06107	Gib		1
8	06208	Handle		1
9	06209	Handle		1
10	06510	Index Ring		1
11	06111	Cover		1
12	06212	Shaft		1
13	06213	Gear Pin	60T	1
14	06214	Gear Shaft	13T	1
15	06215	Gear		1
16	06216	Shaft		1
16A	06415	Bracket		1
17	06417	Cover		1
18	06218	Gear	30T	1
19	06219	Gear	46T	1
22	06220	Gear	63T	1
23	06421	Shift Fork		1
24	06222	Shift Lever		1
25	06223	Shift Handle		1
26	06224	Gear	40T	1
28	06126	Bracket		1
29	06427	Half Nut		1
30	06228	Worm		1
31	06429	Gear	22T	1
32	06230	Shaft		1
33	06231	Gear	18T	1
34	06232	Shaft		1
35	06233	Threading Dial Shaft		1
38	06236	Gear	32T	1
39	06237	Washer		2
40	06238	Bar		1
41	06239	Screw		1
42	06240	Washer		1
43	06241	Washer		1
44	06242	Washer		1
50	06548	Oil Sight Collar		1
51	06459	Oil Sight Collar		1
52	06551	Oil Sight		1
53	06553	Knob		2
54	06554	Plug"A"		1
55	06555	Plug"B"		1
56	06556	Handle		1

57	06257	Spring		1
58	06258	Spring		1
59	06260	Key		1
60	TS-1502031	Hex Socket Cap Screw	M5X12	2
62	TS-1503031	Hex Socket Cap Screw	M6X12	4
63	TS-1503041	Hex Socket Cap Screw	M6X16	1
64	TS-1503061	Hex Socket Cap Screw	M6×25	3
65	TS-1504061	Hex Socket Cap Screw	M8×30	4
66	TS-1504101	Hex Socket Cap Screw	M8×50	1
67	GHB1340-A67	Screw	M5×16	3
68	GHB1340-A68	Screw	M6×12	2
69	GHB1340-A69	Screw	M6×10	2
70	TS-1522011	Set Screw	M5×6	1
71	TS-1523011	Set Screw	M6×6	3
72	TS-1523031	Set Screw	M6×10	1
73	TS-1522051	Set Screw	M5×16	3
74	GHB1340-A74	Set Screw	M6×35	1
75	TS-1523031	Set Screw	M6×10	1
77	GHB1340-A77	Screw	M6×12	1
78	GHB1340-A78	Pin	3×25	1
79	GHB1340-A79	Pin	5×20	2
80	GHB1340-A80	Pin	5×30	2
81	GHB1340-A81	Pin	5×32	1
82	GHB1340-A82	Pin	5×25	3
83	GHB1340-A83	Pin	8n6×12	2
84	GHB1340-A84	Oiler	8	3
85	GHB1340-A85	Washer	8×1.6×2.5	1
86	GHB1340-A86	Lock Washer		1
87	TS-1540031	Hex Nut	M5	3
88	TS-1540041	Hex Nut	M6	2
89	TS-1540061	Hex Nut	M8	1
90	GHB1340-A90	Rivet	2×5	8
91	GHB1340-A91	Rivet	3×8	1
92	GHB1340-A92	O-Ring	20×2.4	1
95	GHB1340-A95	Key	A5×18	1
96	GHB1340-A96	Steel Ball		2
97	GHB1340-A97	Washer	10	1
98	GHB1340-A98	Plug	M10×1	1

Top Slide, Tool Post,Sadle,and Cross Slide



Top Slide, Tool Post,Saddle,and Cross Slide



Top Slide, Tool Post, Saddle, and Cross Slide

Index No.	Part No.	Description	Size	Qty.
1	07101	Saddle		1
2	07102	Cross Slide		1
3	07103	Swivel Slide		1
4	07104	Top Slide		1
5	07111	Collar		1
6	07117	Gib		1
7	07120	Hub		1
8	07123	Strip		1
9	07131	Gib		1
10	07132	Strip		1
11	07141	Front Strip		1
12	07205	Screw		1
13	07206	Handle Base		1
14	07207	Handle Shaft		1
15	07209	Stop		1
16	07210	Screw		1
17	07212	Index Ring		1
18	07213	Lever		1
19	07214	Lever		2
20	07216	Collar		1
22	07219	Washer		1
23	07221	Nut		4
24	07221	Index Ring		1
25	07224	Plate		2
26	07225	Plate w/ Wiper		1
27	07227	Plate		2
28	07229	Screw		1
29	07233	Washer		1
30	07234	Post Base		1
31	07236	Gib Adjusting Screw		2
32	07237	Gib Adjusting Screw		2
33	07238	Lever		1
34	07239	Gib Strip		2
35	07240	T-Bolt		1
36	07415	Block		1
37	07430	Nut		1
38	07508	Knob		1
39	07526	Wiper		2
40	07528	Wiper		1
42	GHB1340-42T	Bearing	8101	2
43	GHB0340-43T	Bearing	8102	2
44	GHB1340-44T	Screw	M4×12	2
45	GHB1340-45T	Screw	M8×12	2
46	GHB1340-46T	Screw	M8×20	1
47	GHB1340-47T	Screw	M8×20	4
48	TS-1503041	Hex Socket Cap Screw	M6×16	1
49	TS-1503051	Hex Socket Cap Screw	M6×20	2
50	TS-1503061	Hex Socket Cap Screw	M6×25	2

52.....	TS-1504031	Hex Socket Cap Screw	M8×16	2
53.....	TS-1523011	Set Screw	M6×6	1
54.....	TS-1523021	Set Screw	M6×8	1
55.....	TS-1523031	Set Screw	M6×10	3
56.....	TS-1523051	Set Screw	M6×16	5
57.....	TS-1524011	Set Screw	M8×8	1
58.....	TS-1524021	Set Screw	M8×10	1
59.....	TS-1540041	Hex Nut	M6	4
60.....	TS-1540061	Hex Nut	M8	2
61.....	GHB1340-61T	Washer	8	2
62.....	GHB1340-62T	Screw	M10×40	8
63.....	GHB1340-63T	Spring	0.6×4×18	1
64.....	GHB1340-64T	Oil Ball	8	6
66.....	GHB1340-66T	Pin	3×16	2
67.....	GHB1340-67T	Pin	3×20	1
69.....	GHB1340-69T	Ball Bearing		2

Saddle and Cross Slide Assembly(Telescoping Lead Screw)



Saddle and Cross Slide Assembly(Telescoping Lead Screw)

Index No.	Part No.	Description	Size	Qty.
1	07101	Saddle		1
2	07102	Cross Slide		1
7	07120N	Hub		1
8	07123	Strip		1
9	07131	Gib		1
10	07132	Strip		1
11	07141	Front Strip		1
12	07205	Screw		1
20	07216	Collar		1
24	07222N	Index Ring		1
25	07224	Plate		1
27	07227	Plate		1
28	07229N	Screw		2
31	07236	Gib Adjsting Screw		1
34	07239	Gib Strip		1
35	07240	T-Bolt		1
36	07415	Block		1
39	07526	Wiper		1
40	07528	Wiper		1
43	GHB1340-43T	Bearing	8102	1
44	GHB1340-44T	Screw	M4×12	1
46	GHB1340-46T	Screw	M8×20	1
47	GHB1340-47T	Screw	M8×20	1
48	TS-1503041	Hex Socket Cap Screw	M6×16	3
50	TS-1503061	Hex Socket Cap Screw	M6×25	4
52	TS-1504031	Hex Socket Cap Screw	M8×16	1
54	TS-1523021	Set Screw	M6×8	1
56	TS-1523051	Set Screw	M6×16	5
58	TS-1524021	Set Screw	M8×10	1
59	TS-1540041	Hex Nut	M6	1
61	07529	Washer		1
64	GHB1340-64T	Oil Ball	8	6
67	07530	Gear Shaft		1
70	GHB1340-70T	Hex Socket Cap Screw	M8×16	1
71	07531	Lever		1
72	07532	Compound Handle		1
73	07533	Spacer		1
74	GHB1340-74T	Key	4×4×20	1
75	GHB1340-75T	Screw	M3×6	1
76	GHB1340-76T	Key	5×5×30	1
77	GHB1340-77T	Thrust Bearing	51101	2
78	07538	Bearing Housing		1
79	07539	Bearing Dust Cover		1
80	07540	Washer		1
81	07541	Star Washer		1
82	07542	Locking Nut		1
83	GHB1340-83T	Hex Socket Cap Screw	M8×25	2

Tailstock Assembly



Tailstock Assembiy



Tailstock Assembly

Index No.	Part No.	Description	Size	Qty.
1	08101	Casting		1
2	08102	Flange Cover		1
3	08103	Hanwheel		1
4	08104	Clamp Plate		1
5	08105	Base		1
	08201	Live Center	MT-3	1
7	08202	Quill		1
8	08203	Screw		1
9	08204	Washer		1
10	08205	Screw		1
11	08206	Screw		1
12	08207	Screw		1
13	08208	Shaft		1
14	08209	Screw		2
15	08211	Collar		1
16	0812	Screw		1
19	08213	Shaft		1
20	08214	Lever		1
21	08401	Nut		1
22	08402	Index Ring		1
23	08403	Pivot Block		1
26	08501	Handle		1
29	GHB1340-29TS	Knob	M8×40	1
30	GHB1340-30TS	Knob	M10×50	1
31	TS-1501031	Hex Socket Cap Screw	M4×10	3
32	TS-1503041	Hex Socket Cap Screw	M6×16	4
33	TS-1522061	Set Screw	M5×20	1
34	TS-1523031	Set Screw	M6×10	1
35	GHB1340-35TS	Set Screw	M10×45	3
36	GHB1340-35TS	Screw	M8×35	1
37	TS-1540061	Hex Nut	M8	1
38	TS-1540081	Hex Nut	M12	1
39	GHB1340-39TS	Key	4×15	1
40	GHB1340-40TS	Washer	B12	1
41	GHB1340-41TS	Pin	5×24	1
42	GHB1340-42TS	Bearing	8102	1
46	GHB1340-43TS	Oil Ball	8	3

Follow Rest



1	GHB1340-1FR	Knob		2
2	GHB-1340-2FR	Pin	3×18	2
3	10208	Bushing		2
4	10204	Screw		2
5	10201	Sleeve		2
6	10401	Brass Finger		2
7	TS-152301	Set Screw	M6×6	2
8	TS-1540041	Nut	M6	2
9	TS-152306	Set Screw	M6×20	2
10	10104	Base Casting		1
11	TS-150409	Hex Socket Cap Screw	M8×45	2

Steady Rest



Steady Rest

Index No.	Part No.	Description	Size	Qty.
1	GHB1340-1FR	Knob		3
2	GHB-1340-2FR	Pin	3×18	3
3	10203	Bushing		3
4	10204	Screw		3
5	10201	Sleeve		3
6	10401	Brass Finger		3
7	10205	Lock Knob		1
8	TS-1540041	Nut	M6	3
9	TS-152306	Set Screw	M6×20	3
10	TS-1540041	Nut	M6	1
11	GHB1340-11SR	Bolt	M6×30	1
12	10206	Pivot Bolt		1
13	10102	Base Casting		1
14	TS-1540081	Nut	M12	1
15	TS-155008	Flat Washer	M12	1
16	TS-152301	Set Screw	M6×6	3
17	10103	Clamp Pad		1
18	GH1340-18SR	Clamp Screw		1
19	10101	Top Casting		1